

### Using Dealer SMS with Mace CS

Using ANY kind of cell phone or device that is SMS (text message) enabled you can..

- Place a system, zone or group on test
- Place all but specific zones on test
- Clear test
- Get test results sent to you
- Get system status on an account including arm/disarm or test status
- Get a list of available commands sent to you

### CS Set up .

1. In the Site Group set up, select the contact you want to have access.
2. Make sure that the contact has the cell phone that is going to be used is part of the contact and that the phone type is cell
3. Set up the phone SMS PIN number for that account

SMS commands. Send to 413.342.2899

The system will authenticate you by asking your PIN number, the session will be valid for 6 hours

All on test times are globally set to four hours

Function	Command String	Sample Command	Results
Help	Help	help	Will return the complete list of commands available to the user
Status	<Xmit#> status	L912345 status	Will return the system status, includes arm/disarm (based on open close signals, on test status
On Test	<SMS Pin> <Xmit#> test	1234 L912345 test	Will place the entire system on test and send you a confirmation that the system is on test
On Test by Point	<SMS Pin> <Xmit#> <pt,pt,pt...> TestList	1234 L912345 1,2,3 testlist	Will place only the requested zones on test and send you a confirmation which zone are on test
On Test by Exception	<SMS Pin> <Xmit#> <pt,pt,pt...> TestExcp	1234 L912345 1,10 testexcp	Will place all zones on test except those in the command and send you a confirmation which zone is on test
On Test By Group	<SMS Pin> <Xmit#> TestGroup	1234 L912345 fire	Will Put all fire zone on test for four hours, will send you a confirmation that the group is on test
Extend	<SMS Pin> <Xmit#> extend	1234 L912345 extend	Will extend the ontest time 4 hours from the time it's received at the cs, a confirmation will be sent back that's its been extended
Clear	<Xmit#> clear	L912345 clear	Clears test immediately and will send you a confirmation that the site is no longer on test
Test Results	<SMS Pin> <Xmit#> results	1234 L912345 results	Displays test results by zone number only